

ROBOT PERCEPTION 3

TASK 2 : Sobel Filter

Name: Aniruddhan

Reg: 21BRS1682

Aim: To apply the Sobel Filter to get the edge detection, in order to know image boundaries.

Algorithm:

Step 1: Import Required Libraries

1. Import necessary libraries:
 - numpy: For handling arrays and performing numerical operations.
 - scipy.ndimage: For applying the Sobel filter, which is used to detect edges in images.
 - skimage.io: For reading and saving images.
 - skimage.color: For converting color images to grayscale.
 - skimage.util: For converting image formats.
 - matplotlib.pyplot: For displaying images.

Step 2: Load and Convert Image to Grayscale

1. Define the path to the image file.
2. Load the image using `io.imread(image_path)`.
3. Convert the loaded image to grayscale using `color.rgb2gray(image)`. Grayscale conversion simplifies the image to a single channel, which is ideal for edge detection.

Step 3: Define the Sobel Filter Function

1. **Sobel Filter Function:**

- Define a function `sobel_filter(image)` that takes a grayscale image as input.
 - Apply the Sobel filter along the x-axis using `ndi.sobel(image, axis=0)`, which detects vertical edges.
 - Apply the Sobel filter along the y-axis using `ndi.sobel(image, axis=1)`, which detects horizontal edges.
 - Compute the gradient magnitude using `np.hypot(sobel_x, sobel_y)`, which combines the results from both axes to detect overall edge strength.
 - Normalize the gradient magnitude to a range of $[0, 1]$ by subtracting the minimum value and dividing by the range (difference between the maximum and minimum values).
2. **Return the normalized magnitude** as the result of the Sobel filter function.

Step 4: Apply the Sobel Filter to the Grayscale Image

1. Call the `sobel_filter(gray_image)` function with the grayscale image as input.
2. Store the result in `sobel_result`, which contains the edge-detected image.

Step 5: Convert the Filtered Image to 8-bit Format

1. Define a function `convert_to_ubyte(image)` that converts the filtered image to 8-bit format using `util.img_as_ubyte(image)`. This step ensures compatibility with standard image formats and prepares the image for saving or further processing.
2. Convert the `sobel_result` to 8-bit format and store the result in `sobel_result_ubyte`.

Step 6: Save the Sobel Filtered Image

1. Save the 8-bit Sobel-filtered image to disk using `io.imsave('sobel_filtered_image.png', sobel_result_ubyte)`.

Step 7: Display the Sobel Filtered Image

1. Define a function `display_image(image, title)` that takes an image and a title as input.

- Use `plt.figure(figsize=(8, 8))` to create a new figure for the image.
 - Display the image using `plt.imshow(image, cmap='gray')` to show it in grayscale.
 - Set the title using `plt.title(title)` and hide the axis using `plt.axis('off')`.
 - Use `plt.show()` to display the image.
2. Call the `display_image(sobel_result, 'Sobel Filter')` function to visualize the Sobel-filtered image.

Code:

```
import numpy as np
import scipy.ndimage as ndi
from skimage import io, color, util
import matplotlib.pyplot as plt

# Load and convert image to grayscale
image_path = "/content/img1.jpg"
image = io.imread(image_path)
gray_image = color.rgb2gray(image) # Convert to grayscale

# Sobel Filter
def sobel_filter(image):
    sobel_x = ndi.sobel(image, axis=0)
    sobel_y = ndi.sobel(image, axis=1)
    magnitude = np.hypot(sobel_x, sobel_y)
    # Normalize magnitude to [0, 1]
    magnitude = (magnitude - np.min(magnitude)) / (np.max(magnitude) - np.min(magnitude))
    return magnitude

# Apply filters
sobel_result = sobel_filter(gray_image)

# Convert results to 8-bit format
def convert_to_ubyte(image):
    return util.img_as_ubyte(image)

sobel_result_ubyte = convert_to_ubyte(sobel_result)

io.imsave('sobel_filtered_image.png', sobel_result_ubyte)
```

```
# Display images using matplotlib
def display_image(image, title):
    plt.figure(figsize=(8, 8))
    plt.imshow(image, cmap='gray')
    plt.title(title)
    plt.axis('off') # Hide axis
    plt.show()

display_image(sobel_result, 'Sobel Filter')
```

O/P:

Sobel Filter

